



STEP 1 - GETTING STARTED

Remove the Sandwich Board from the carrying case.



STEP 2 - OPEN WIDE

Place the front legs onto the ground and holding the back frame, gently pull back to open the frame. Once the frame is open place the back feet onto the ground and position for maximum visibility.