




## STEP 1: GETTING STARTED

Remove the tent from the bag and place it at your desired location.

With another person, separate the legs of the tent until they are extended a full arms length.



## STEP 2: UNFOLD CANOPY


Unfold your Canopy and drape over the tent's Frame. Attach the Canopy by connecting the loop strips on the canopy corners with the hook strips on the frame's four legs. Position the canopy's apex with the center pole of the Frame.



## STEP 3: PULL AWAY FROM EACH OTHER


Be sure the Canopy's apex is on top of the centre pole of the entire Frame.

Stand diagonal to each other and separate the frames legs. The frame will open a little at a time so alternate ends until the frame no longer expands.



## STEP 4: LOCK THEM UP TIGHT

Lift the expanding section of the frame upwards until the four sliding connectors lock into place on the frame's legs.



### STEP 5: STAND STURDY

Once set, release and extend the telescoping legs. Raise the tent to your desired height and lock the legs into place.



### STEP 6: TWIST & TIGHT

Lift the apex of the canopy up into place by turning the crank located on the center of the expanding frame.

Turn counter-clockwise until the canopy is taut.