

## ZAP 88 & 118,5cm



Bag, protective cassette, telescopic rod, spotlight



1. Remove ZAP from the bag.



2. Turn the foot 90°.



3. Attach the metal rod by inserting it into the base.



4. Insert the rod into the hole in the top bar.



5. Attach the spotlight to the top bar.



6. Extend the rod to its full height.



Zap 88cm.



Zap 118,5cm.

## Double ZAP



Bag, protective cassette, telescopic rod, spotlight



1. Turn the foot 30°



2. Raise the first graphic panel.



3. Roll out the other graphic panel.



4. Lean ZAP against you.



5. Fit the top bar onto the rod.



6. Raise ZAP when holding the rod.



7. Turn the foot 90°



Double ZAP.