

TENSION FABRIC INSTRUCTIONS

EXHALE SETUP



Position Exhale frame with bottom hubs on ground and fabric facing forward.



Standing behind Exhale unit, grasp center scissor tubes and pull upward and outward to expand the frame.



Starting with center hubs, grasp opposing front and rear hubs and pull together so that hooked tie rods lock in place. Repeat locking all opposing hooks together to secure frame in expanded configuration.



If fabric wraps around ends of frame, secure end flaps by adhering Velcro backing at ends of fabric to Velcro tabs on back row of end hubs.

TENSION FABRIC INSTRUCTIONS

EXHALE TAKE-DOWN



Where present, detach Velcroed fabric end flaps from backside end hubs. Do not detach fabric from webbing on front of frame. The Exhale system may be stowed with the fabric graphic attached.



Squeeze together opposing hubs to release hooked tie rods. Leave one pair of hooks locked until ready to collapse frame. Once last hook is released, ease frame downward and inward until partially collapsed.



CAUTION: Ensure that all hooked tie rods are disengaged when collapsing or damage to unit may result. If frame binds while expanding or collapsing, check that all hooks are disengaged and that Velcro backing on fabric end flaps is not sticking to itself or to Velcro end tabs on frame. Never use excessive force to try and force frame closed.

Tip frame backward so that fabric is on top. Gently tuck fabric between quads and close frame tight.



Changing Fabric: To straighten or change fabric graphic, expand and lock frame. Detach Velcro backing on fabric from end hub tabs and web straps. To reapply graphic, make sure that ALL opposing tie rods are hooked together. Starting from one end, Velcro fabric to top and bottom end tabs, then work from end to end along frame, Velcroing fabric to webbing on frame so that graphic is taut and wrinkle free.